

# HOW TO SHUT OFF GAS IN AN EMERGENCY

The main shut-off valve is located on the inlet pipe next to your gas meter. Using a wrench or some other suitable tool, give the valve a quarter turn in either direction so that it is crosswise to the pipe (see drawing). Gas must be turned on again by a PG&E gas service man. Please call your local PG&E business office for service.

